

Instructions

Cable Covers

All of AIRLINKTECH's fiberglass composite parts are delivered over-sized.

NOTE: your covers have scribe lines.

The scribe lines outline the cutouts for the various tabs and tubes of the fuselage. We recommend that you cut the fiberglass composite a little at a time until you reach the scribe line, periodically trying the parts for proper fit. Each cage is slightly different, so work your way to the scribe mark.

Fasten the covers to the vertical fuselage tubes, one on the right, one on the left, using 1" wide Velcro pieces. If the cables or cable turnbuckles rub on the covers, protect them with VHBT chafe tape (S/H # 033-01001-01). The easiest way to fasten the joint is by using Tinnerman U-type fasteners (NAS 395), Aircraft Spruce # A1932-8Z-1.

Be sure to de-wax parts before painting.